

Slides, videos, links and more:

<https://github.com/physicell-training/ws2021>

# Session 11: Intracellular Modeling




Furkan Kurtoglu

 @FKurtogluSysBio

## PhysiCell Project

July 28, 2021



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

**PhysiCell.org**

 @PhysiCell

# What we have learned so far

- PhysiCell folder structure
- PhysiCell model domain
  - Different dts (diffusion\_dt, mechanic\_dt, phenotype\_dt)
- Using GUI to create config file (XML)
- PhysiCell C++ functions

# What we will learn

- Basics of Kinetic Modeling (ODE Model)
- How to integrate kinetic models to ABM
- How to control phenotype based on intracellular model
- Kinetic ODE solver (libRR) related functions
- How to save intracellular data
- How to make faster your simulation with losing convergence

# Agenda:

- First Session
  - PhysiCell 1.9.0
  - Kinetic SBML
  - PhysiCell Integration
    - Model Design
    - Results
    - Convergence Tests
  - libRR Add-on
    - Functions
    - Phenotypic Changes
  - Sample Model
    - Description
    - Basic Domain Creation (If we can)

# PhysiCell 1.9.0

- PhysiCell 1.9.0
  - Released: 12 July 2021
- Major new features
  - Includes three intracellular modeling approaches
    - ◆ Boolean Network => PhysiBoSS
    - ◆ Kinetic Modeling (ODEs) => libroadrunner
    - ◆ Flux Balance Analysis => PhysidFBA
  - New Intracellular Object in Phenotype
    - ◆ All intracellular packages basic generic functions with same syntax
      - » Start(), Update(), get\_parameter(), set\_parameter(), ...
    - ◆ Some special functions specific to packages
      - » get\_boolean\_variable\_value(PhysiBoSS) validate\_SBML\_species (ODE), ...

# 3 Sample Projects


- PhysiBoSS
  - physiboss-cell-lines-sample
- Libroadrunner
  - ode-sample-project
- PhysidFBA
  - cancer-metabolism

# Installation


- Each add-on requires related solver
  - PhysiBoSS – MaBoSS
  - PhysidFBA – coin-clp
  - Libroadrunner – Libroadrunner (no surprise!)
- To install related solver, you need to populate sample-project, first
  - make ode-energy-sample
- Then, compile once.
  - make

# PhysiBoSS

- Boolean Network
  - MaBoSS
- SysBioCurie & BSC



- <https://github.com/gletort/PhysiBoSS>
  - Fully integrated as “add-on” to PhysiCell
- We had an optional morning session
  - Please visit [agenda](#) for slides and video






# PhysidFBA

- Aims to couple ABM and FBA.
- Miguel Ponce de Leon
- Approach will be explained in future slides.
- <https://github.com/migp11/PhysiCellFBA>
  - Added alpha version as “add-on” to PhysiCell.

## a) Genome-scale metabolic reconstruction



## b) Flux balance analysis

Maximize/minimize an objective function  
 $Z = c_1 v_1 + c_2 v_2 + \dots + c_j v_j$ , such that:


$$\begin{matrix} & \text{Reactions} \\ & R_1 & R_2 & R_3 & R_4 & R_5 \\ \text{Metabolites} & \begin{pmatrix} -1 & 0 & 0 & 0 & 0 \\ 1 & -1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 & -1 \\ 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & -1 & 0 \\ 0 & 0 & 0 & 1 & -1 \\ 0 & 0 & 0 & 0 & 1 \end{pmatrix} \end{matrix} \otimes \begin{pmatrix} v_1 \\ v_2 \\ v_3 \\ v_4 \\ v_5 \end{pmatrix} = \begin{pmatrix} 0 \\ 0 \\ 0 \\ 0 \\ 0 \end{pmatrix}$$

S-matrix

Flux vector

and for every reaction  $i$ :  $lb_i < v_i < ub_i$

## c) Solution spaces



Heirendt et al, 2017

# Libroadrunner

- Integrating intracellular kinetic models to individual agents.
- Individual phenotype changes according to molecular simulations
  - Intracellular values (Molecular Concentrations, Signal Transductions, i.e.)
    - ◆ Intracellular oxygen deficiency in cell leads to change necrosis rate.
    - ◆ Intracellular amino acids levels define the cellular growth / cycle rate.
- Opens new opportunities for PhysiCell syntax
  - Users can utilize SBML to model phenotypic behaviors.
  - Since molecular values can edit phenotypic parameters in SBML, PhysiCell interface is getting changed.
- LibRR is developed by
  - Herbert Sauro and Andy Somogyi
  - C++ API

# SBML

- Systems Biology Mark-up Language
- Reaction – Stoichiometry
- Kinetic – Pseudo Steady State
  - Kinetic – Ordinary Differential Equations
  - Pseudo Steady State – Optimization (Flux Balance Analysis)
- Hard to read for Human (xml file)
- Parsed according to some rules.

```
[...]  
<species metaid="heme"  
  id="heme"  
  compartment="Comp01"  
  initialConcentration="0">  
  <annotation>  
    <rdf:RDF xmlns:rdf="http://www.w3.org/1999/02/22-rdf-syntax-ns#"  
      xmlns:bqbiol="http://biomodels.net/biology-qualifiers/">  
      <rdf:Description rdf:about="#heme">  
        <bqbiol:hasPart>  
          <rdf:Bag>  
            <rdf:li rdf:resource="urn:miriam:uniprot:P69905" />  
            <rdf:li rdf:resource="urn:miriam:uniprot:P68871" />  
            <rdf:li rdf:resource="urn:miriam:obo.chebi:CHEBI%3A17627" />  
          </rdf:Bag>  
        </bqbiol:hasPart>  
      </rdf:Description>  
    </rdf:RDF>  
  </annotation>  
</species>  
[...]
```



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# SBML

- Compartments
  - Volumetric Entities
- Species
  - Chemicals
- Reactions
  - Stoichiometric Relations
  - Boundaries (Lower and Upper) (FBA)
- Global Quantities
  - Parameters
  - Constants

```
▼ COPASI
  ▼ Model
    ▼ Biochemical
      ▼ Compartments [1]
        Intracellular
      ▼ Species [4]
        Energy
        Glucose
        Lactate
        Oxygen
      ▼ Reactions [3]
        Aerobic
        Anaerobic
        Energy_Usage
      ▼ Global Quantities [3]
        k_aer
        k_ane
        k_usage
```

#	Name	Reaction	Rate Law	Flux [mmol/min]	Noise Expression
1	Aerobic	Glucose + 6 * Oxygen -> 38 * Energy	Mass action (irreversible)	nan	
2	Anaerobic	Glucose -> 2 * Energy + Lactate	Mass action (irreversible)	nan	
3	Energy_Usage	Energy ->	Mass action (irreversible)	nan	
	New Reaction				



**LUDDY**


SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# Kinetic Modeling



#	Name	Reaction
1	Aerobic	Glucose + 6 * Oxygen -> 38 * Energy
2	Anaerobic	Glucose -> 2 * Energy + Lactate
3	Energy_Usage	Energy ->
	New Reaction	


$$\frac{d([Glucose] \cdot V_{Intracellular})}{dt} = -V_{Intracellular} \cdot (k_{aer} \cdot [Glucose] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen]) - V_{Intracellular} \cdot (k_{ane} \cdot [Glucose])$$

$$\frac{d([Oxygen] \cdot V_{Intracellular})}{dt} = -6 \cdot V_{Intracellular} \cdot (k_{aer} \cdot [Glucose] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen])$$

$$\frac{d([Energy] \cdot V_{Intracellular})}{dt} = +38 \cdot V_{Intracellular} \cdot (k_{aer} \cdot [Glucose] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen] \cdot [Oxygen]) + 2 \cdot V_{Intracellular} \cdot (k_{ane} \cdot [Glucose]) - V_{Intracellular} \cdot (k_{usage} \cdot [Energy])$$

$$\frac{d([Lactate] \cdot V_{Intracellular})}{dt} = +V_{Intracellular} \cdot (k_{ane} \cdot [Glucose])$$

**Concentrations, Volumes, and Global Quantity Values**




# SBML


- General SBMLs have more than one compartment
  - Extracellular
  - Intracellular
  - Mitochondria (Sometimes)
  - Nucleus (?)
- And have two or more species for one substrate
  - $\text{Glucose}[e] \Rightarrow \text{extracellular}$
  - $\text{Glucose}[i] \Rightarrow \text{intracellular}$
- Transfer reaction between compartments
  - $\text{Glucose}[e] = \text{Glucose}[i]$

# Assumptions

- **But ...**
- PhysiCell has transfer reactions through
  - BioFVM
- So, we can support specific type of SBMLs
  - Only Intracellular (might have more than one compartment – Mitochondria, Nucleus)
- Well-Structured SBMLs
  - **Not all SBMLs are supported!!!**
    - ◆ No External Compartment and Transfer Reactions in SBML!
    - ◆ Mapping is needed between SBML & PhysiCell
  - Works on each diffusion\_dt (0.01 min)
    - ◆ (as default for best convergence)



# Integration Design






# Performance Test

- More than 50,000 cells
- 4 substrate (internalization is on)
- 5 SBML species (4 reactions)
- 4000x4000x20  $\mu\text{m}$  dimensions ( $dx = 20 \mu\text{m}$ )
- Personal PC
  - AMD 6 core 3.0 GHz, 16 GB RAM
  - 8-thread, OpenMP


	1 min output	60 min output
No SBML solver	11 secs	1 min 57 secs
SBML solver	20 secs	16 min 35 secs

Current time: 0 days, 0 hours, and 0.00 minutes,  $z = 0.00 \mu\text{m}$   
50637 agents



# How about intracellular\_dt

- Default 0.01 min but...
- Imagine cell is like pool with source and sink
  - A = uptaking a chemical from microenvironment
  - B = secreting a chemical to microenvironment
- If diffusion\_dt and intracellular\_dt is same,
  - They are matching dt's so there is no convergence difference.
  - But it is slow!
- (Figure to be drawn during presentation)



# How about intracellular\_dt

- However, we can change intracellular\_dt.
- Let's assume that we made it 1.00 min (100 times slower)
- How it will look like (Figure to be drawn during presentation)
- So much faster
  - You will see in the Demo

# How it looks

- Config File

```
<cell_definitions>
  <cell_definition name="default" ID="0">
    <phenotype>
      <cycle code="5" name="live">
        <!-- using higher than normal significant digits to match divisions in default code -->
        <transition_rates units="1/min">
          <rate start_index="0" end_index="0" fixed_duration="false">0.0</rate>
        </transition_rates>
      </cycle>
      <death>
      <volume>
      <motility>
        <speed units="micron/min">0.0</speed>
        <persistence_time units="min">0.1</persistence_time>
        <migration_bias units="dimensionless">.9</migration_bias>
        <options>
          <enabled>true</enabled>
          <use_2D>true</use_2D>
          <chemotaxis>
            <enabled>false</enabled>
            <substrate>oxygen</substrate>
            <direction>1</direction>
          </chemotaxis>
        </options>
      </motility>
      <secretion>
      </phenotype>
```



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# Some Results



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING


PhysiCell Project

**PhysiCell.org**

 **@PhysiCell**

# Model 0 - SBML Model

- 4 Species
  - Oxygen
  - Glucose
  - Lactate
  - Energy
- 3 Internal Reactions
  - ♦ Aerobic reaction
    - »  $\text{Glucose} + \text{Oxygen} \rightarrow \text{Energy}$
  - ♦ Anaerobic reaction
    - »  $\text{Glucose} \rightarrow \text{Energy} + \text{Lactate}$
  - ♦ Energy Usage
    - »  $\text{Energy} \rightarrow$



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING


PhysiCell Project

PhysiCell.org

@PhysiCell

# Model 0

- Very Simple SBML toy model
- Both simulated in PhysiCell and Copasi
- No Transfer Reaction in SBML
- No Uptake Rate
- Only solving SBML



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING



PhysiCell Project

PhysiCell.org

@PhysiCell

# Model 1

- Uptake glucose, oxygen
- Produces Energy internally.






# SBML Events

## Cycle Rate

- If Energy level is smaller than 50 a.u.
  - Equals to zero 1/min
- If Energy level is greater than 50 a.u.
  - Equals to 0.01 1/min



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project


PhysiCell.org

@PhysiCell

# Model 2

- Phenotypic changes according to SBML species
- Organoid (2D) seeding.
- Lactate Secretion Rate increases
  - Lactate Concentration
- If oxygen level is less than threshold
  - Cells increase their migration speed
- If Energy level is less than threshold
  - Cells go apoptosis

# Microenvironment Results



**LUDDY**



SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# Lactate Secretion



**LUDDY**


SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project



PhysiCell.org

@PhysiCell

Current time: 0 days, 0 hours, and 0.00 minutes,  $z = 0.00 \mu\text{m}$   
144 agents



# Intracellular



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

[PhysiCell.org](https://PhysiCell.org)

[@PhysiCell](https://twitter.com/PhysiCell)

# How it looks

- Config File

```
<cell_definitions>
  <cell_definition name="default" ID="0">
    <phenotype>
      <cycle code="5" name="live">
        <!-- using higher than normal significant digits to match divisions in default code -->
        <transition_rates units="1/min">
          <rate start_index="0" end_index="0" fixed_duration="false">0.0</rate>
        </transition_rates>
      </cycle>
      <death>
      <volume>
      <motility>
        <speed units="micron/min">0.0</speed>
        <persistence_time units="min">0.1</persistence_time>
        <migration_bias units="dimensionless">.9</migration_bias>
        <options>
          <enabled>true</enabled>
          <use_2D>true</use_2D>
          <chemotaxis>
            <enabled>false</enabled>
            <substrate>oxygen</substrate>
            <direction>1</direction>
          </chemotaxis>
        </options>
      </motility>
      <secretion>
      </phenotype>
```



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# SBML-Phenotypic Parameters


PhysiCell Phenotype Parameter	First letter	phenotype_token	example
Phase Transition Rate	c	ctr_**	ctr_0_1
Death Rate	d	da,dn	da,dn
Persistence Time	m	mpt	mpt
Migration Speed	m	mms	mms
Migration Bias	m	mmb	mmb
Uptake rate	s	sur_*	sur_oxygen
Secretion rate	s	ssr_*	ssr_glucose
Saturation density	s	ssd_*	ssd_oxygen
Export rate	s	ser_*	ser_lactate
Target solid cytoplasmic	v	vtsc	vtsc
Target solid nuclear	v	vtsn	vtsn
Target fluid fraction	v	vff	vff



# Libroadrunner Addon

- Same format for intracellular addons. (PhysiFBA, PhysiBoSS)
- Libroadrunner
  - **start()** = start intracellular in cell (it should be used after seeding and is called after proliferation)
  - **Initialize\_SBML()** = to read SBML (users will not use)
  - **get\_values()** = to get value from SBML
  - **set\_values()** = to set value in SBML
  - **update()** = to simulate SBML
  - **get\_state()** = to get the name of SBML
  - **update\_phenotypic\_parameters()** = to update phenotype according to given tokens
  - **validate\_tokens()** = to validate given token
  - **validate\_species()** = to validate SBML species

# Integration Design



# Migration Speed


## Cell Definition

```
<motility>
```

```
  <persistence_time units="min">0.1</persistence_time>
  <migration_bias units="dimensionless">.9</migration_bias>
  <options>
```

```
<intracellular type="roadrunner">
  <sbml_filename>./config/Toy_oxy_mms_tr_01.xml</sbml_filename>
  <map PC_substrate="oxygen" sbml_species="Oxy"></map >
  <map PC_custom data="PC_Test_CD" sbml_species="death_rate"></map>
</intracellular>
```

Current time: 0 days, 0 hours, and 0.00 minutes, z = 0.00  $\mu\text{m}$   
1 agents





# Chemokine Distribution

## Cell Definition

```
<secretion_target units="substrate density">10</secretion_target>  
<uptake_rate units="1/min">0.0</uptake_rate>  
<net_export_rate units="total substrate/min">0</net_export_rate>  
</substrate>
```

```
<intracellular type="roadrunner">  
  <sbml_filename>./config/Toy_oxy_mms_tr_01.xml</sbml_filename>  
  <map PC substrate="oxygen" sbml species="Oxy"></map >  
</intracellular>
```



# Wrong Tokens

```
<intracellular type="roadrunner">
  <sbml_filename>./config/Toy_oxy_mms_tr_01.xml</sbml_filename>
  <map PC_substrate="oxygen" sbml_species="Oxy"></map >
  <map PC_custom_data="PC_Test_CD" sbml_species="death_rate"></map>
  <map PC_phenotype="ctr00" sbml_species="transition_rate_0_1"></map>
  <map PC_phenotype="ssr1" sbml_species="secretion_rate_Lactate"></map>
</intracellular>
```

PS C:\Users\Furkan\Documents\GitHub\PhysiCell-SBML-trials\PhysiCell\_intracellular\_Phenotype>

E



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# Code walk

- Let's do code walk together...

# PhysidFBA



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING


PhysiCell Project

**PhysiCell.org**

 **@PhysiCell**

# Flux Balance Analysis

## a) Genome-scale metabolic reconstruction



## b) Flux balance analysis


Maximize/minimize an objective function  
 $Z = c_1 v_1 + c_2 v_2 + \dots + c_n v_n$ , such that:

	Reactions					
	R <sub>1</sub>	R <sub>2</sub>	R <sub>3</sub>	R <sub>4</sub>	R <sub>5</sub>	
Metabolites	-1	0	0	0	0	$S \cdot v = b$
	1	-1	0	0	0	
	0	1	-1	0	0	
	0	1	0	0	-1	
	0	0	1	0	0	
	0	0	0	-1	0	
	0	0	0	1	-1	
	0	0	0	0	1	

S-matrix      Flux vector

and for every reaction  $i$ :  $lb_i < v_i < ub_i$


## c) Solution spaces



Heirendt et al, 2017



# Integration Design



# PhysidFBA

- FBA is like taking a photo
- dFBA is like stop-motion video.
- dFBA simulates intracellular model
  - Finds optimal biomass creation flux
  - This value is used for volume calculation (growth of cell)
  - If cell is greater than the volume threshold
    - ◆ Divide
    - ◆ Arrest function

# LibRoadRunner Interactive Demo



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

**PhysiCell.org**

 **@PhysiCell**

# Model

- Three Substrates
  - Oxygen, Glucose, Lactate
  - Energy is created with two reactions
    - ♦  $\text{Glucose} + \text{Oxygen} \rightarrow 38 * \text{Energy}$  (Aerobic)
    - ♦  $\text{Glucose} \rightarrow 4 * \text{Energy} + \text{Lactate}$  (Anaerobic)
  - Energy consumes
    - ♦  $\text{Energy} \rightarrow$  (Energy\_Usage)
- Phenotypic Tokens
  - migration speed, apoptosis\_rate, lac\_Secretion\_Rate, Transition\_Rate

# Model Rules

- Initial Energy = 450
- If Energy > 445
  - Cycle
- If Energy < 445
  - Don't Cycle
- If Energy < 440
  - Move
- If Energy < 430
  - Die

# Populate together

- **PhysiCell folder**
- make clean
- make data-cleanup
- make reset
- make list-projects
- make ode-energy-sample
- make



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING


PhysiCell Project

**PhysiCell.org**

 **@PhysiCell**

# Demo Model

- Domain size
  - $X = [-500, 500]$
  - $Y = [-500, 500]$
  - $Z = [-10, 10]$
  - $dx, dy, dz = 20$
  - $Use\_2D = true$
- Max-time = 1440 min
- Thread = your choice
- Save data : SVG = 30 min,



Full = 30 min

# Demo Model

- Microenvironment Tab
- Let's add “oxygen”, “glucose”, “lactate”

The screenshot shows the 'NEW' tab in the PhysiCell software. On the left, under the heading '--- Substrate ---', there is a list of substrates: 'oxygen', 'glucose', and 'lactate'. The 'glucose' entry is currently selected and highlighted in blue. To the right of this list, there are several input fields for defining the substrate's properties, each followed by a square bracket indicating it is a required field. These fields are: 'diffusion coefficient', 'decay rate', 'initial condition', 'Dirichlet BC', 'Dirichlet options per boundary:', 'xmin:', 'xmax:', 'ymin:', 'ymax:', 'zmin:', and 'zmax:'. At the bottom of the right-hand panel, there is a section labeled 'For all substrates:'.



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

**PhysiCell Project**


**PhysiCell.org**

 **@PhysiCell**




# Demo Model

- Oxygen
- Diffusion Coefficient = 100.0 micrometers<sup>2</sup>/min
- Decay Rate = 0.0 1/min
- Initial condition = 38.0 mmHg
- Dirichlet = OFF
- Track in agents = ON




# Demo Model

- Glucose
- Diffusion Coefficient = 300.0 micro
- Decay Rate = 0.0 1/min
- Initial condition = 50.0 a.u
- Dirichlet = OFF
- Track in agents = ON




# Demo Model

- Lactate
- Diffusion Coefficient = 300.0 mic
- Decay Rate = 0.0 1/min
- Initial condition = 0.0 mmHg
- Dirichlet = OFF
- Track in agents = ON



# Cell Type

- Only one type of cell in the name of “default”
- Cycle
  - Live Cells
  - Transition rate(s)
  - 0.0



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

PhysiCell.org

@PhysiCell

# Cell Type

- No Death

Apoptosis

death rate  1/min

☐ transition rate ☐ duration

phase 0->1 transition rate  0.0 ☐ Fixed min

phase 0 duration  516 ☒ Fixed min

---

unlysed fluid change rate  0.05 1/min

lysed fluid change rate  0 1/min

cytoplasmic biomass change rate  1.66667e-02 1/min

nuclear biomass change rate  5.83333e-03 1/min

calcification rate  0 1/min

relative rupture volume  2.0

Necrosis

☐ duration

phase 0->1 transition rate  0.0 ☐ Fixed 1/min

phase 1->2 transition rate  0.0 ☐ Fixed 1/min

phase 0 duration  0 ☒ Fixed min

phase 1 duration  86400 ☒ Fixed min

---

unlysed fluid change rate  0.05 1/min

lysed fluid change rate  0 1/min

cytoplasmic biomass change rate  1.66667e-02 1/min



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING



PhysiCell Project

PhysiCell.org

@PhysiCell


# Cell Type

- No change in the Volume and Mechanics Tab



# Cell Type

- Motility
- Speed = 0.0
- Persistence Time = 0.1
- Migration Bias = 0.9
- Enable-motility



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING


PhysiCell Project

[PhysiCell.org](https://PhysiCell.org)

[@PhysiCell](https://twitter.com/PhysiCell)

# Cell Type : Secretion


- Oxygen Tab
- Uptake rate = 0.005






# Cell Type : Secretion

- Glucose Tab
- Uptake rate = 0.001



# Cell Type : Secretion

- Lactate Tab
- Secretion Target = 10.0



**LUDDY**

SCHOOL OF INFORMATICS, COMPUTING, AND ENGINEERING

PhysiCell Project

**PhysiCell.org**

 **@PhysiCell**

# Cell Custom Data

- We need to create intracellular data to save the data
- $\text{intra\_oxy} = 0.0$
- $\text{intra\_glu} = 0.0$
- $\text{intra\_lac} = 0.0$
- $\text{intra\_energy} = 0.0$

[illegible]

# User Params

- `initial_internal_oxygen` (double) = 0.8
- `initial_internal_glucose` (double) = 15
- `initial_internal_lactate` (double) = 0.0
- `initial_energy` (double) = 450

PhysiCell Model Builder: copy\_template.xml

File Tools

Config Basics Microenvironment Cell Types Cell Custom Data User Params

Append 5 more rows Clear selected rows

	Name	Type	Value	Units
<input type="checkbox"/>	random_seed	int	0	dimensionless

Description:

Description:

☐ double 0.0

Description:

☐ double 0.0

Description:

☐ double 0.0

Description:

☐ double 0.0

Description:

☐ double 0.0

Description:

☐ double 0.0

Description:

☐ double 0.0

# Save

- Let's look is it right.
- In my case, it did not put cell custom data
- I went to custom data in cell types tab
- And just make them 0.0
- Saved again.
- It worked!

# Let's Add Intracellular Attribute

```
<intracellular type="roadrunner">
```

```
  <sbml_filename>./config/Toy_Metabolic_Model.xml</sbml_filename>
```

```
    <map PC_substrate="oxygen" sbml_species="Oxygen"></map >
```

```
    <map PC_substrate="lactate" sbml_species="Lactate"></map >
```

```
    <map PC_substrate="glucose" sbml_species="Glucose"></map >
```

```
    <map PC_phenotype="da" sbml_species="apoptosis_rate"></map>
```

```
    <map PC_phenotype="mms" sbml_species="migration_speed"></map>
```

```
    <map PC_phenotype="ssr_lactate" sbml_species="Lac_Secretion_Rate"></map>
```

```
    <map PC_phenotype="ctr_0_0" sbml_species="Transition_Rate"></map>
```

```
</intracellular>
```

# Funding Acknowledgements



## PhysiCell Development:

- Breast Cancer Research Foundation
- Jayne Koskinas Ted Giovanis Foundation for Health and Policy
- National Cancer Institute (U01CA232137)
- National Science Foundation (1720625)

## Training Materials:

- Administrative supplement to NCI U01CA232137 (Year 2)